



TAG BRACKET INSTALLATION:

1. Remove the passenger pegs
2. Place the bracket on the outside of the sub frame over the rear bolt holes for the pegs.
3. Place the pegs back over the holes and insert rear bolt.
4. Use 2 of the 4 washers on each of the front bolts for the pegs and insert them between the peg and the sub frame. This will space the pegs evenly.
5. Adjust the tag to the angle you desire and tighten bolts.

2005/2006 bikes: The right side (short side) will bolt behind the rear brake reservoir.

HUGGER INSTALLATION:

Install the hugger in its original location and route the wire through the left side of the swing arm shock and up the left side of the bike. Wire can be brought up the sub frame just below the front seat and attached to the stock white connection located at the rear of the bike. Black wire on the hugger will be attached to the green wire on the bike.

Any questions please email me at Sales@TripageLED.com or visit TripageLED.com