



Ram Air led install

Drill a 25/64 hole in the spots where the led's are in the picture, Front row of holes on each side is left stock. Insert the led's as pictured and attach them using hot glue or a glue of some sort. Cover the entire assembly with silicone to ensure no shorting from water. Run the wire in desired location and attach to stock turn signals. Red is positive and black is negative. Green is negative on the signals.

