



Third Eye Installation

1: Remove third eye cover.



2: Remove stock light and rubber housing.

3: Turn bulb housing to remove the bulb socket.



4: Pull the wires through the housing. Using scotch locks (16-14 quick splice #85404) you can attach the wires without having to cut the wires. Or, cut the wires and attach them with butt splices or solder and heat shrink them.

5: Insert led in the housing and reinstall the cover.



(Bike) green = (Third eye) Black

(Bike) Brown = (Third eye) Red